## **STEP ONE**

## Connect the Shelf Boards to the Back Wall

1

Lay out back wall panel on the work surface.

2

Insert the shelf boards into the routed holes on the bottom rail.

Push until the locking tabs snap into place.

3

Insert the two side walls into the back wall panel as shown. Note the tabbed rail will go on the bottom.

4

Align and insert the front wall to the assembly, ensuring all the shelf boards snap into place and side walls are inserted.

5

Using the provided 5/8" screws, fasten the side wall to the front and back wall from the inside of the posts as shown.

Each post will use two screws.









